

ScourStop™ Instructions Cohesive Soils



1

← 2nd or 3rd hole from edge

← Extras, as needed

← Overlap mats to minimize anchor requirements

Parallel

Position anchors to secure ScourStop mats flush with soil surface. Minimize gaps or bridging. Add extra anchors if necessary, or improve soil surface smoothness.

Anchor requirements*:

First Row of Mats**
- minimum of 8 anchors/mat

Second+ Row of Mats**
- minimum of 5 anchors/mat

*To achieve consistent contact with the soil, exceed the minimum anchor requirement at installation.

**Perpendicular to flow.

2

Insert the machined end of the driver into the bullet anchor.

36" long

Clean the machined end each time to ensure easy release when removing driver.

3

Ground Rod driver

Electric Hammer (minimum 6 lb. striking force, 11 lb. best for cohesive soils) Slide hammers are also available.

Insert the bullet driver into the ground rod driver and vibrate the bullet into the ground a minimum depth of 18 inches (450 mm) 36 inches (900 mm) for sandy soils.

ScourStop

4

Twist and pull the driver out.

5

Pull strap to 'set' anchor in position.

18"-36" deep

6

Insert bullet tail into lock/washer.

7

Use pliers to 'set' lock/washer down onto ScourStop mat with firm down pressure.

©2010 Leggett & Platt, Incorporated · 9365_0610 · Patent Pending



320 SE Delaware Ave. Suite 5 · Ankeny, Iowa 50021
1-877-997-2687 · f: 515-289-0710 · www.scourstop.com

the green solution to rip rap
scourstop™